

INSTALLATION INSTRUCTIONS

M1-4203


THREE HANDLE THERMOSTATIC ROUGH WITH FLOW CONTROL & 2-WAY DIVERTER, TO SUIT M1-4404 & X1-2013


M1-4404

CROSS HANDLE THERMOSTATIC WITH LEVER FLOW CONTROL & 2-WAY DIVERTER TRIM ONLY, TO SUIT M1-4203 ROUGH

M1-4203

M1-4404







LEFROY BROOKS


Dimensions in Inches (& Millimetres)

M1-4203



M1-4404





<u>5 5/16"</u> (135mm) <u>2 1/2"</u> (63.5mm)

Whilst every effort is made to ensure accuracy, design and dimensions are subject to change without notice as part of the company's product development process.

What you need to know

Tools:

Adjustable Wrench Groove Joint Pliers Hacksaw Phillips Screwdriver Pipe Tape Spatula Spirit Level



Safety Tips

If you are soldering during faucet installation, remove cartridges, seats, gaskets and washers prior to applying flame, otherwise you will void the warranty.

Cover drain openings to avoid losing small parts.

When cutting or soldering pipe, use safety glasses to protect your eyes.

Maintenance

Your new bathroom faucet is designed for years of trouble-free performance.

Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, wire wool and harsh chemicals as these will dull the finish and void your warranty.

Important Points

Prior to beginning installation. turn off the cold and hot water lines and open the old faucet to release built-up pressure.

Overtightening nuts may cause damage.

Wrap all threaded connections with pipe tape available at your local plumbing supply store. Always wrap in a clockwise direction. The fittings should be installed by a state-licenced plumber.

Please note:

When there is a difference in water pressure between hot and cold supplies to the mixing valve, the pressures should by equalized by a plumber in accordance with best practice and legislation.


Things You May Need

Correct installation may vary depending on previous faucet installation. All necessary supplies required for faucet installation are not included, but may be found where plumbing supplies are sold. It is suggested that IAPMO and/or CSA approved plumbing supplies are used during installation.

Standards

IAPMO/cUPC Listed Meets A112.18.1 Meets ASSE 1016 (Only M1-4203)

Flow Rate




Please note :

Final achievable flow rate is dependent on the outlets fitted, see relevant outlets (spouts, roses, sprays) for fully assembled product flow rate.

Steps 1-4

Installation Procedure

Lefroy Brooks always recommends that plumbing products be installed by a licensed professional. Shut off main water supply before installation.



3

4

- Before installing the valve into the wall, 3 please note that a distance between 80mm~105mm from the wall surface to the rear of the valve should be left so that the trim can be fitted correctly.
 - Install valve assembly into the wall.


Cut a hole on the wall surface for fitting the trim kit. The hole dimension is as shown in figure 3.

Throw away the protective caps only when building construction is completed and you are ready to fit the trim kit in. REMOVE CAP ONLY, KEEP THE REST OF THE MUD GUARD AS IT IS NEEDED TO HOLD THE TRIM FIXING SCREWS.

2

Steps 5-8 Installation Procedure

Lefroy Brooks always recommends that plumbing products be installed by a licensed professional. Shut off main water supply before installation.



Я

Take out the stopper.

5


6

Turn on the flow controller. Turn the thermostatic cartridge until the water temperature is at 38. Suggestion: attach a hose to the outlets and guide the water to the basin or another container to test the temperature and prevent it from spilling on the floor. Turn off the water supply. Install the stopper and make sure its "B" plane as shown is horizontal and on the left side.


Fix the stem extension and the adjusting ring.

Steps 9-12 Installation Procedure

Lefroy Brooks always recommends that plumbing products be installed by a licensed professional. Shut off main water supply before installation.




Exploded View Parts List



1	Spindle (017119)
2	O-ring (048038)
3	Nut (009111)
4	O-ring (063060)
5	Spring (005060)
6	Cartridge (024092)
7	Oil-seal (010113)
8	Rubber protective cap
	(045432)
9	Sleeve (067946)
10	Cartridge assembly (507455)
11	Body (076707)
12	Body (076706)
13	O-ring (048017)
14	Adaptor (067945)
15	O-ring (004096N)
16	Body (076697)
17	Diverter cartridge (507775N)
18	Adjusting ring (104291)
19	Rubber protective cap
	(038008)
20	Thermostatic cartridge
	(507132)
21	Set screw (053009)
22	Pin (003146)
23	Adjusting ring (104061)
24	Stopper (049108)
25	Plaster guard (127215)
26	Screw (008241)

M1-4404



1	$C_{crover}(0.0010C)$
1 2	Screw (008186) Spindle (110388)
2	
	Clip (012242)
4	Screw (008189)
5	Canopy (018960)
6	Handle (029686)
7	Set screw (292598)
8	Button (036272)
9	Spring (005157)
10	Handle (029685)
11	Screw (008994)
12	Adaptor (067960-50)
13	Pin (003147)
14	Screw (008196)
15	Canopy (018959-50)
16	Spindle (110386)
17	Set screw (065086)
18	Adjusting ring (104295)
19	Front plate (006582-51)
20	Seal (010939)
21	Seal (013817)
22	Allen key (031003)
23	Allen key (031000)
20	/ (1011 (0) (0) 1000)

For additional assistance or service call

718-302-5292

9am to 5pm EST Monday to Friday



LEFROY BROOKS

www.lefroybrooks.com

LEFROY BROOKS INC, 1828 TROUTMAN STREET, RIDGEWOOD, NY, 11385 TELEPHONE: 718-302-5292. FAX: 718-302-4177

The use of trademarks, product design and artwork is subject to licence or agreement with LBIP Ltd. The design registrations, trademark registrations and copyrights are protected by law and the use or reproduction outside the terms of an agreement is prohibited. The right to modify designs and dimensions is reserved. Christo Lefroy Brooks is a member of ACID (Anti Copying in Design).